

MACHINE SPARES

TORNADOR M-2010



Nº	Item number	Name
2	T-102A	Plastic nozzle for M-2010.
3	MT-105U	Flexible pipe nozzle assembly
4	MT-106U	Handle extension for M-2010. M-2040.
5	MT-107U	Trigger holder
6	MT-108U	Trigger holder screw holder screw
7	MT-109U	Tornador trigger universal
8	MT-110U	Outer body screw
9	MT-111U	Body connector screw
10	MT-112U	Inner bushing universal
11	MT-113U	Gasket universal bushing
12	MT-114U	Valve stem universal
13	MT-115U	Valve spring universal
14	MT-116U	Inner thin tube with thread lock
15	MT-117U	Air reversing tap universal
16	MT-118U	Bottom universal tap connector screw.

Nº	Item number	Name
17	MT-119U	Tank cap with hole universal
18	MT-120U	Tank cap gasket
19	MT-121U	Connecting screw nut
20	MT-122U	Plastic tank inner tube
21	MT-123U	Plastic tank
22	MT-124A	Bottom air adapter. handle
23	MT-125U	Two threaded body screw universal
24	MT-126U	Body screw gasket universal
25	MT-127U	Gasket sleeve
26	MT-128U	Inner screw O-ring
27	MT-129U	Plastic nozzle O-ring.
28	MT-130U	Plastic body gasket universal
29	MT-132U	Metal tank ball
30	MT-131U	Internal valve stem gasket
31	MT-120U	Tank cap gasket universal.