


## MACHINE SPARES

# TORNADOR M-2020



Nº	Item number	Name
1	MT-208B	M2020 nozzle
2	MT-200K	Wrapping turbine for M2020
8	MT-201U	Handle extension for M-2020 and M-2030.
9	MT-130U	Universal plastic case gasket
10	MT-125U	Two-cut screw of universal housing
11	MT-108U	Holder screw trigger holder screw
12	MT-107U	Trigger holder
13	MT-126U	Universal body screw gasket
14	MT-110U	External screw of housing
15	MT-111U	Housing connecting screw
16	MT-128U	Inner screw O-ring
17	MT-127U	Bushing gasket
18	MT-131U	Internal valve stem gasket
19	MT-112U	Multipurpose inner bushing
20	MT-113U	Universal bushing gasket

Nº	Item number	Name
21	MT-114U	Universal valve stem
22	MT-115U	Universal valve spring
23	MT-109U	Universal trigger
24	MT-209A	Inner thin tube with threaded retainer M-2020 M-2030
25	MT-117U	Multipurpose air reversing valve
26	MT-118U	Universal crane lower connecting screw
27	MT-119U	Multipurpose tank cover with hole
28	MT-214U	Universal tank cover gasket
29	MT-132U	Metal tank ball
30	MT-121U	Screw connection nut MT118U
31	MT-123U	Plastic tank
32	MT-101U	Universal housing handle
33	MT-330U	Lower air regulator (1/4" PF)
33	MT-330N	Lower air regulator (1/4"NPT)