


MACHINE SPARES

TORNADOR M-2030



Nº	Item number	Name
1	MT-205K	Plastic M-2030 nozzle.
8	MT-201U	M-2020 handle extension, M-2030
9	MT-130U	Universal plastic case gasket
10	MT-125U	Two-cut screw of universal housing
11	MT-108U	Holder screw trigger holder screw
12	MT-107U	Trigger holder
13	MT-128U	Inner screw O-ring
14	MT-110U	External screw of housing
15	MT-111U	Housing connecting screw
16	MT-126U	Universal body screw gasket
17	MT-131U	Internal valve stem gasket
18	MT-127U	Bushing gasket
19	MT-112U	Multipurpose inner bushing
20	MT-113U	Universal bushing gasket
21	MT-114U	Universal valve stem

Nº	Item number	Name
22	MT-115U	Universal valve spring
23	MT-109U	Universal trigger
24	MT-209A	Inner thin tube with threaded retainer M-2020 M-2030
25	MT-117U	Multipurpose air reversing valve
26	MT-118U	Universal crane lower connecting screw
27	MT-119U	Multipurpose tank cover with hole
28	MT-214U	Universal tank cover gasket
29	MT-132U	Metal tank ball
30	MT-121U	Screw connection nut MT-118U
31	MT-123A	Plastic tank (new)
32	MT-101U	Universal housing handle
33	MT-330U	Lower air regulator
34	MT-122U	Plastic tank inner tube
37	MT-133U	Inner washer of M-2020 tank cover, M-2030