


MACHINE SPARES

TORNADOR M-2040 TURBO



Nº	Item number	Name
1	MT-101U4	Housing handle M-2040
2	MT-200N	Plastic M-2040 nozzle.
3	MT-205N	Rotating turbine assembly for M-2040
4	MT-106U	M-2010 handle extension, M-2040
5	MT-107U	Trigger holder
6	MT-108U	Holder screw trigger holder screw
7	MT-109U	Tornado's trigger is universal
8	MT-110U	External screw of housing
9	MT-111U	Housing connecting screw
10	MT-112U	Multipurpose inner bushing
11	MT-113U	Universal bushing gasket
12	MT-114U	Universal valve stem
13	MT-115U	Universal valve spring
14	MT-203N	Inner thin tube with threaded retainer for M-2040
15	MT-117U	Multipurpose air reversing valve

Nº	Item number	Name
16	MT-118U	Connecting screw of the lower university crane.
17	MT-119U	Multipurpose tank cover with hole
18	MT-214U	Universal tank cover gasket
19	MT-121U	Screw connection nut MT-118U
20	MT-122U	Plastic tank inner tube
21	MT-123U	Plastic tank
22	MT-124A	Handle bottom air adapter
23	MT-125U	Two universal screw of the housing
24	MT-126U	Universal body screw gasket
25	MT-127U	Bushing gasket
26	MT-128U	Inner screw O-ring
27	MT-205A	Adapter for two threaded turbine
28	MT-130U	Universal plastic case gasket
29	MT-132U	Metal tank ball
30	MT-131U	Internal valve stem gasket